






Start Water Flow



Start Continuous Water Flow



Change Water Temperature and Water Flow



For the sensors to operate properly, your finger must be held right below the LED, at a height of 0.5 inches. Your finger must be held steadily for a duration of 0.4 seconds.

©2013 Muirsis, Inc. 714-579-1555 www.muirsismedical.com